



## ASSEMBLY INSTRUCTION SHEET



**SUNPAN**  
**MODERN HOME**  
sunpan.com

Description : THATCHER DINING CHAIR






Item No: 103037/102797/102743



Please visit our website [www.sunpan.com](http://www.sunpan.com) for more great products .

For assembly questions please call 1-800-787-1019 (or +14167360094)outside North America  
or email to [info@sunpan.com](mailto:info@sunpan.com)

### PARTS LIST

Before you begin, please layout all parts and ensure you have the correct count

No	DESCRIPTION	Qty	ILLUSTRATION
A	SEAT	1	
B	FRAME	1	
C	BOLT (M6x16mm )	4	
D	ALLEN WRENCH (M6)	1	
E	GASKET(M6×18×1.5mm)	4	

STEP	DESCRIPTION	
1	Attach Seat(A) to Frame(B) with GASKET(E) and Bolt(C) by using Allen Wrench(D).	
2	Complete assembly.	

### ASSEMBLY TIPS:

- Please check parts and hardware before assembling. Follow each instruction step by step.
- Place a protective pad or piece of cardboard on the floor while assembling your item on top of it.
- Remove all parts from the carton and separate them into part numbers/groups as indicated on the part list.
- Please Follow instructions in the sequence as numbered to assure fast/easy assembly.

### WARNING:

- Don't attempt to repair or modify parts that are broken or defective . if you find a broken part please contact the retailer where you purchased it for replacement.
- Keep all hardware parts out of the reach of children.

### FURNITURE CARE:

Following these few basic steps will help to ensure that you enjoy your furniture for a long time:

- Do not expose your furniture to direct sunlight, dampness or any heat,such as a hot cup of coffee or tea. Always use a coaster.
- Excessive exposure to sunlight may cause fading
- Excessive temperature and humidity or cold may cause cracking or splitting
- Dust with a clean, damp, lint free cloth
- Use a damp cloth with water or mild detergent to clean all surfaces . Do not use chemicals or paint thinner which will fade the surface.
- Place a piece of felt or a pad under the legs of your furniture to avoid scratching the floor.