



Contact (866) 758-3900 for assistance.
Do not return to place of purchase.

Assembly Instructions

Model No. F-1665

Hardware/Parts

1	Handle (4)	61-F1665-HD
2	Poker	61-F1665-PK
3	Tongs	61-F1665-TN
4	Yoke	61-F1665-YK
5	Base Rod	61-F1665-BSR
6	Base	61-F1665-BS
7	Shovel Rod	61-F1665-SLR
8	Shovel	61-F1665-SL
9	Brush Rod	61-F1665-BHR
10	Brush Cap	61-F1665-BHC
11	Brush	61-F1665-BH

Steps

Step 1

Attach handles to poker, shovel rod, tongs and brush rod.

Step 2

Attach base to base rod. Attach yoke to base rod.

Step 3

Attach shovel to shovel rod.


Step 4

Attach brush to brush cap to brush rod.

Step 5

Place assembled poker, shovel, log lifter and brush on yoke.

▲ CAUTION: Keep this product clean by using a damp cloth. DO NOT use abrasive cleaners, as it will cause parts to tarnish.





Pour toute assistance, appeler le 1.866.758.3900.
Ne pas retourner au point de vente.

Instructions d'assemblage Modèle n° F-1665

Quincaillerie/Pièces

❶	Poignée (4)	61-F1665-HD
❷	Tisonnier	61-F1665-PK
❸	Pinces	61-F1665-TN
❹	Collier de support	61-F1665-YK
❺	Tige du socle	61-F1665-BSR
❻	Socle	61-F1665-BS
❼	Tige de la pelle	61-F1665-SLR
❽	Pelle	61-F1665-SL
❾	Tige du balai	61-F1665-BHR
❿	Protège-balai	61-F1665-BHC
⓫	Balai	61-F1665-BH

Étapes

Étape 1

Fixez les poignées aux tiges du tisonnier, de la pelle, du balai et de la pince à bûches.

Étape 2

Fixez la tige du socle dans le socle. Fixez le collier de support à la tige du socle.

Étape 3

Fixez le balai au protège-balai puis à la tige du balai.

Étape 4

Placez le tisonnier, la pelle, le balai et la pince à bûches sur le collier de support.

ATTENTION : Veiller à ce que cet article demeure propre en le nettoyant à l'aide d'un chiffon humide. NE PAS utiliser de nettoyants abrasifs car ils risquent de ternir les pièces.

