



### Important safety instructions:

- Please read carefully all instructions before assembling.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.





### Pre-assembly:

- Do not discard any content until assembly is completed to avoid accidentally discarding small parts or hardware.
- Remove all parts and hardware from box along with any protective packaging.

### Parts List

| Item | Description | DRAWING   | QTY |
|------|-------------|---|-----|
| P1   | Chair Top   |  | 1   |
| P2   | Legs        |  | 4   |

### Hardware List


| Item | Description            | DRAWING   | QTY |
|------|------------------------|---|-----|
| H1   | ALLEN WRENCH           |  | 1   |
| H2   | Bolts<br>φ5/16*1"      |  | 16  |
| H3   | Lock Washers<br>φ5/16" |  | 16  |
| H4   | Flat Washers<br>φ5/16" |  | 16  |

### DISCLAIMER:


WHEN PROPERLY ASSEMBLED, THIS ITEM IS SAFE FOR INTENDED USE. SELLER IS NOT LIABLE FOR ANY DAMAGES RESULTING FROM ITEM BEING IMPROPERLY ASSEMBLED AFTER PURCHASE.

### Assembly Procedures:

Step 1. Assemble the chair on soft, scratch-free surface such as a carpet or a rug. Turn the chair (P1) upside down on the carpet, attach four legs (P2) to the bottom chair by using bolts (H2), lock washers (H3) and flat washers (H4), tighten all bolts with allen wrench (H1).



Step 2. Place chair upright on a level surface. Assembly is complete.



### Additional note about safety:

Bolts may loosen during normal everyday use.

They should be inspected at least every 3 months and re-tightened as needed to prevent damage or injury, and ensure stability.

Thank you for your purchase