



ASSEMBLY INSTRUCTION

SUNPAN





Sunpan Product Name: **LYLA COUNTER STOOL**







Please visit our website www.sunpan.com for more great products

For assembly questions please call **1-800-787-1019 (or +1-416-736-0094)** outside North America or email to info@sunpan.com




PARTS LIST

Before you begin, please layout all parts and ensure you have the correct count.

PARTS	DESCRIPTION	QUANTITY	ILLUSTRATION
A	Seat	1	
B	Leg Bar	2	
C	Leg 1	1	
D	Leg 2	1	

E	Footrest	1	
F	Bolt (M6x30mm)	2	
G	Countersunk Bolt (M6x35mm)	4	
H	Allen Wrench (M6)	1	
I	Allen Wrench (M5)	1	
J	Bolt (M6x35mm)	2	

ASSEMBLY INSTRUCTIONS

STEPS	DESCRIPTION	ILLUSTRATION
1	Connect Leg 1 (C), Leg 2 (D) and the Leg Bar (B). Attach the Footrest (E) to the assembled leg frame with the Countersunk Bolts (G) by using the Allen Wrench (I).	
2	Attach the leg frame to the Seat (A) with the Bolts (F & J) by using the Allen Wrench (H).	
3	Assembly completed.	

ASSEMBLY TIPS:

Please check parts and hardware before assembling. Follow each instruction step by step.
 Place a protective pad or piece of cardboard on the floor while assembling your item on top of it.
 Remove all parts from the carton and separate them into part numbers/groups as indicated on the part list.
 Please follow instructions in the sequence as numbered to assure fast/easy assembly.

WARNING:

Don't attempt to repair or modify parts that are broken or defective - if you find a broken part please contact us for replacement.
 Keep all hardware parts out of the reach of children.

FURNITURE CARE:

Following these few basic steps will help to ensure that you enjoy your furniture for a long time:
 Do not expose your furniture to direct sunlight, dampness or any heat, like a hot cup of coffee or tea. Always use a coaster.
 Excessive exposure to sunlight may cause fading.
 Excessive temperature and humidity or cold may cause cracking or splitting.
 Dust with a clean, damp, lint free cloth.
 Use a damp cloth with water or mild detergent to clean all surfaces - do not use chemicals or paint thinner which will fade the surface.
 Place a piece of felt or a pad under the legs of your furniture to avoid scratching the floor.