

**ASSEMBLY INSTRUCTIONS**  
**ALASKA DINING CHAIR**


**ITEM NO.: 3385-02**  
**DEMENSION: W21.68" X D24.8" X H36.2"**

**PART LIST**



**DO NOT FULLY TIGHTEN SCREWS AND BOLTS UNTIL THE ENTIRE ITEM IS COMPLETELY ASSEMBLED**

**(A)** Back assembly  
(1pc)


**(B)** Front legs-(2pcs)  
put inside the  
seat cushion




**(C)** Back legs-(2pcs)  
put inside the seat  
cushion



**NOTICE**




**STEP 1**



Step1:Put the screws in the holes,tighten the screws,but not too tighten,90% is ok.

**STEP 2**



Step 2:Put the screws in the holes,tighten the screws,but not too tighten,80% is ok.

**HARDWARE LIST**

Screw D

Screw E

Flat washer F



(1) M8X55MM  
(4PCS)

(2) M8X65MM  
(4PCS)

(3) 8pcs

Spring washer G


Allen key H



(4) 8pcs


M8  
(5) 1PC

**STEP 3**



Step 3: Then adjust the balance of this chair,tighten all the screws to100%.

**STEP 4**



Step4 :Finally,zip up the non-woven cover underneath the seat.