

ASSEMBLY INSTRUCTION FOR COFFEE TABLE

FIGURE 1



1. Place top upside down on soft and even surface. (Figure 1)

2. Remove the bolts/washers from the holes in the side panels. Use the wrench provided. (Figure 1)

FIGURE 2



3. Match up the numbers corresponding with each hole. (Figure 2)

FIGURE 3



4. Tighten bolts and washers with the wrench provided. (Figure 3)

FIGURE 4



5. Ensure that every piece is securely tightened and turn right side up. (Figure 4)

Care and Maintenance

- For general cleaning, use a soft dry cloth.
- Do not use polish, soaps, detergents, or aerosol or sprays on the product
- Do not place hot, cold or wet items directly on the surface
- This product is solid wood and made for indoor use only.

HARDWARE INCLUDED

BOLT = 4 PCS, Allen BOLT = 4 PCS, WASHER = 8 PCS, SPANER = 1 PC, Allen Key= 1 PC, EXTRA FLAT PAD = 4