

ASSEMBLY INSTRUCTION FOR CONSOLE TABLE

FIGURE 1



1. Place top upside down on soft and even surface. (Figure 1)

2. Remove the bolts/washers from the holes in the side panels. Use the wrench provided. (Figure 1)

FIGURE 2



3. Match up the numbers of holes of first Side Panel corresponding with each hole and Tighten bolts and washers with the wrench provided (Figure 2)

FIGURE 3



4. Match up the numbers of holes of Second Side Panel corresponding with each hole and Tighten bolts and washers with the wrench provided (Figure 3)

FIGURE 5



5. set shelf Between Panels as per figure 3 and Tighten bolts and washers with the wrench provided.

FIGURE 5



6. Ensure that every piece is securely tightened and turn right side up. (Figure 5)

Now your console Table is ready to use.

Care and Maintenance

- For general cleaning, use a soft dry cloth.
- Do not use polish, soaps, detergents, or aerosol or sprays on the product
- Do not place hot, cold or wet items directly on the surface
- This product is solid wood and made for indoor use only.

HARDWARE ICLUDED

BOLT = 4PCS, Allen BOLT = 4, WASHER= 8 PCS,
Spanner = 1 Pc, Allen Key = 1,
EXTRA FLAT PAD = 4

