



ASSEMBLY INSTRUCTION




Product Name: **PETRA DINING CHAIR**




PARTS LIST



Before you begin, please layout all parts and ensure you have the correct count.

NO.	DESCRIPTION	QUANTITY	ILLUSTRATION
1	Right Side Frame	1	
2	Left Side Frame	1	
3	Front Stretcher	1	
4	Back Stretcher	1	
5	Top Rest	1	
6	Cushion Seat	1	
A	JCBC M6 x 30mm + S/W M6 + F/W M6 x 13mm	4	
B	JCBC Screw M6 x 50mm + S/W M6 + F/W M6 x 13mm	2	
C	JCBC Screw M6 x 55mm + S/W M6 + F/W M/6 x 13mm	2	
D	Allen Key M4	1	
E	L-Bracket	4	
F	PH Screw M4 x 12mm	8	
G	Wood Dowel M8 x 25mm	2	
H	Protective Disc 22mm	4	

ASSEMBLY INSTRUCTIONS

STEP	DESCRIPTION	ILLUSTRATION
1	<p>Slot in Front Stretcher (3) and Back Stretcher (4) into the both Right Side Frame (1) and Left Side Frame (2) as shown. Please make sure that Front Stretcher (3) has a small hole for identification.</p>	
2	<p>Place the dining chair upside down on the table, fix JCBC Bolt (B) into Front Stretcher (3) and JCBC Bolt (C) into Back Stretcher (4) then tighten the bolts by using Allen Key (D). Do not fully tighten the bolts yet.</p>	
3	<p>Align Top Rest (5) through the bolt holes into the both Side Frame (1 & 2). Then, fix JCBC Bolt (A) into the hole and tighten it by using Allen Key (D). The tighten step for JCBC Bolt can refer to the picture.</p>	

<p>4</p>	<p>Please fully tighten the bolt now by using Allen Key (D).</p>	 <p>ATTENTION : PLEASE FULLY TIGHTEN THE BOLT NOW.</p>
<p>5</p>	<p>Fix the Wood Dowel (G) into the designated hole at the Right Side Frame (1).</p>	
<p>6</p>	<p>Place the dining chair upside down on the table, fix Cushion Seat (6) with L-Bracket (E) and PH Screw (F). Tighten it by using Screwdriver (not provided).</p>	

<p>7</p>	<p>Paste Protective Disc (H) at each legs as shown.</p>	
<p>8</p>	<p>Assembly completed.</p>	

ASSEMBLY TIPS:

Please check parts and hardware before assembling. Follow each instruction step by step.
 Place a protective pad or piece of cardboard on the floor while assembling your item on top of it.
 Remove all parts from the carton and separate them into part numbers/groups as indicated on the part list.
 Please follow instructions in the sequence as numbered to assure fast/easy assembly.

WARNING:

Don't attempt to repair or modify parts that are broken or defective - if you find a broken part please contact us for replacement.
 Keep all hardware parts out of the reach of children.

FURNITURE CARE:

Following these few basic steps will help to ensure that you enjoy your furniture for a long time:
 Do not expose your furniture to direct sunlight, dampness or any heat, like a hot cup of coffee or tea. Always use a coaster.
 Excessive exposure to sunlight may cause fading.
 Excessive temperature and humidity or cold may cause cracking or splitting.
 Dust with a clean, damp, lint free cloth.
 Use a damp cloth with water or mild detergent to clean all surfaces - do not use chemicals or paint thinner which will fade the surface.
 Place a piece of felt or a pad under the legs of your furniture to avoid scratching the floor.