











ITEM NAME / NOM D'ITEM: NIDA DINING TABLE

ITEM # / NO.ITEM: 109957

PARTS LIST / LISTE DES PIÈCES


(1)	(2)	(3)	(4)
			
x1	x2	x2	x1

(5)


A. M6 x 30MM 	x14	B. M8 x 30MM 	x4	C. Ø6MM 	x14
D. Ø6MM 	x14	E. 5MM 	x1	F. 4MM 	x1

ASSEMBLY INSTRUCTIONS / INSTRUCTIONS D'ASSEMBLAGE


I




II



III



IV



Please use the attached adjustable footpads to level the chair on uneven surface.

For missing parts or damaged parts, please call /
 Pour pièce manquante ou endommagée, veuillez appeler:

USA, Canada and Mexico : (866)798-6663

AI-V1-240520